

HOOK03 Coat Hook (No buffer)

12mm +

Does not include fixings		
Panel thickness	ANODISED	PPC
12mm +	HOOK03A	HOOK03P

1. Position the coat hook and using the fixing holes as a guide mark the door.
2. Remove the coat hook and predrill the door. Being careful not to go all the way through.
3. Re position the coat hook and fix in place with the correct fixings.
4. Check the coat hook is secured properly.

