

# Toilet ROLL HOLDER T01

12mm +

Includes universal fixings		
Panel thickness	ANODISED	PPC
12mm +	T01A1221	T02P1221

1. Position the Toilet Roll Holder and using the fixing holes as a guide mark the panel.
2. Remove the Toilet Roll Holder and predrill the door. Being careful not to go all the way through.
3. Re position the Toilet Roll Holder and fix in place with the correct fixings.
4. Check the Toilet Roll Holder is secured properly.
5. Insert the sprung loaded tube.

