

# IB 12 PILASTER LATCH

12-13mm

| Includes universal fixings |          |                      |
|----------------------------|----------|----------------------|
| Panel thickness            | ANODISED | PPC STANDARD F-PLATE |
| 12-13mm                    | N/A      | IB12P121302          |

1. Decide the centre height of the indicator bolt (this is usually personal preference). Mark off and machine as shown below, include the rebate on flush fitting faceplates only.
2. Set the orientation by adjusting the movement restrictor screw, once set fit the correct Lock/Unlock sticker to the signal.
3. Fit the drive bar into the square in the indicator handle, offer the lock body to the panel and position the signal and faceplate on the other side. Clamp the two halves together with the M4 screws.
4. Close the door and check the operation of the latch.

