


# B3 BB1 Channel Bracket

19-21mm

Includes fixings for wall and fascia fix		
Panel thickness	ANODISED	PPC
19-21m	B319BB1A	B319BB1P



1. Mark off the centreline position on the wall.
2. Determine the position of the brackets on the centreline and mark the two hole positions per bracket.
3. Drill the holes  $\text{Ø}5.5$  to a minimum depth of 50mm.
4. Insert the six 32mm plastic plugs into the holes.
5. Secure the brackets to the wall plugs using the No.8 x 2" screws provided.
6. Repeat step one on the fascia panel.
7. Determine the position of the brackets on the fascia and mark off the six hole positions.
8. Use a small drill to pilot the six holes to a max. depth of 14mm. Take care not to break through the front face of the panel.
9. Secure the brackets to the fascia with the six No.8 x 5/8" screws provided.
10. Set the partition into the wall brackets ensuring the height and level are correct.
11. Drill through the pre-drilled brackets using a  $\text{Ø}7\text{mm}$  drill.
12. Secure the panel to the brackets using the Brass Bush and Clutch Head Screws provided as shown above.
13. Repeat steps 10-12 for the fascia panel fitting to the partition.