



# Vanity Unit Installation



# Cubicle Fittings




20mm L Bracket




40mm L Bracket


## Tools Required




Cordless Drill




Hammer Drill



Tape Measure



Pencil




Hammer



Spirit Level



Jig Saw



Metal Jig Saw Blades


# Step 1

1. Drill and secure timber batten against structural wall to allow for the underside of the top to be supported.

## Fixing Positions

The batten should be **838mm** from the floor to the top of the batten.

**No timber battens are supplied.**




# Step 2

1. Drill and secure a timber batten inside the vanity base unit on the floor to secure the frame in position from the inside.

## Fixing Positions

**600mm Depth Top - 537mm** from back structural wall to front edge of batten

**400mm Depth Top - 337mm** from back structural wall to front edge of batten






# Step 3

1. Attach and secure vanity base end panel to the front base frame with **4 x 40mm L Brackets** provided.




# Step 4

1. Carefully lift into place the vanity base frame into the corner of the wall making sure the frame is tight up against the timber floor batten.
2. Fix and secure the end panel with 4 x 40mm L brackets provided where the panel butts up against the structural wall.
3. Fix and secure the bottom plinth from the inside of the unit to the timber floor batten with 20mm L brackets provided.



# Step 5

1. Mark out the sink basins positions on the vanity top using the sink template provided by sink supplier.
2. Cut out sink basins using a jig saw cutter with a metal jig saw blade.
3. No sink basins are provided with the vanity units.





# Step 6

1. Remove the front vanity access panel to get inside the unit and secure the vanity top down onto the base frame using 20mm L Brackets provided.
2. Pre drill the bracket holes, where you have marked on the underside of the vanity top using a **3mm drill bit**
3. Make sure you use 9.5mm screws provided to fix the brackets into the 12mm vanity top
4. Once you have completed securing the vanity top and all plumbing service pipes have been connected you can clip back on the front access panel.

